

# KIT PRINCE



KIT PRINCE 24V
2 PRINCE 24V,
1 T2 24V-CRX electronic control board,
1 SPARK aerial (without cable),
1 SUN 2CH 2-channel transmitter,
1 pair of FIT SLIM photocells,
1 BLOCK key selector,
1 SPARK blinker,
1 warning plate and instructions manuals.

FOR SWING GATES LEAVES WEIGHING UP TO 200 kg AND UP TO 2 m LONG

AD00732 KIT PRINCE 24V (with impact sensor)

# KIT PRINCE Wi-Fi



KIT PRINCE 24V Wi-Fi
2 PRINCE 24V,
1 T2 24V electronic control board,
1 MASTER Wi-Fi,
1 SUN 2CH 2-channel transmitter,
1 pair of NOVA Wi-Fi PHOTOCELLS without wires,
1 BLOCK Wi-Fi key selector without wires, with batteries
1 SPARK Wi-Fi blinker without wires,
1 warning plate and instructions manuals,
4 batteries AA 1,5V for NOVA Wi-Fi PHOTOCELLS,
3 batteries C 1,5V for SPARK Wi-Fi blinker.



FOR SWING GATES LEAVES WEIGHING UP TO 200 kg AND UP TO 2 m LONG

AD00734 KIT PRINCE 24V Wi-Fi (with impact sensor)