

# KIT PREMIER



## KIT PREMIER 24V


- 1 PREMIER 24V (MASTER) with built in T2 24V-CRX pc board,
- 1 PREMIER 24V (SLAVE),
- 2 standard levers,
- 1 SPARK aerial (without cable),
- 1 SUN 2CH 2-channel transmitter,
- 1 pair of FIT SLIM photocells,
- 1 BLOCK key selector,
- 1 SPARK blinker,
- 1 warning plate and instructions manuals.

FOR SWING GATES LEAVES WEIGHING UP TO 300 kg AND UP TO 2 m LONG

AD18010

KIT PREMIER 24V

# KIT PREMIER Wi-Fi



## KIT PREMIER 24V Wi-Fi

- 1 PREMIER 24V (MASTER) with built in T2 24V control board,
- 1 PREMIER 24V (SLAVE),
- 2 standard levers,
- 1 MASTER Wi-Fi,
- 1 SUN 2CH 2-channel transmitter,
- 1 pair of NOVA Wi-Fi PHOTOCELLS without wires,
- 1 BLOCK Wi-Fi key selector without wires, with batteries,
- 1 SPARK Wi-Fi blinker without wires,
- 1 warning plate and instructions manuals.
- 4 batteries AA 1,5V for NOVA Wi-Fi PHOTOCELLS,
- 3 batteries C 1,5V for SPARK Wi-Fi blinker.



FOR SWING GATES LEAVES WEIGHING UP TO 300 kg AND UP TO 2 m LONG

AD18011

KIT PREMIER 24V Wi-Fi