


RS232 Card

The RS232 Card facilitates connection to a Visualeyez Alarm Monitoring workstation.

795-122 RS232 Card

Internal view of DXc2 panel with RS232 card fitted



RS232 Kit

Mimics and Repeaters

Mimics and Repeaters

Mimic

Allows geographic 'floor map' zonal indicators to be built for situations where increased clarity of the fire location is required above that given by the standard numbered zonal indicators.

Both mimic driver and Expansion mimic cards support 16 zones and can be connected together to create up-to a 160 zone system.

020-909 DXc Compact Mimic Driver LEDs

020-910 DXc Expansion Mimic PCB

